




INSTALLATION | RapidConnect® floor drain for freestanding tubs



Installation:

- Cut 5" (12,7 cm) hole into wood sub-floor (use supplied Cutout Template).
- Affix to sub-floor with 5 screws (not supplied)
- Connect Drain assembly to desired P-Trap below floor.

- Install flooring surface, leaving a 5" opening to access Drain.
- Affix the appropriate brass Tailpiece to the Waste & Overflow. **NOTE: DO NOT CUT THE BRASS TAILPIECE AS THIS MAY CAUSE A LEAK.** Ensure the measurement between the base of the Drain and P-Trap will accommodate the Tailpiece.

- Grip centre Tab with Channel Locks and rock back and forth till removed. Apply lubricant (supplied) to the Tailpiece.
- Position assembled Tub in-line with Drain.
- Carefully lower the Tub with installed brass Tailpiece into the Red Collar Drain assembly. Ensure Tailpiece is fully engaged with Seal.

Important : DO NOT CUT THE SUPPLIED BRASS TAILPIECE.

Doing so may cause a leak. Disassembling the Drain or cutting the Tailpiece will void the warranty.



INSTALLATION | RapidConnect® drain de plancher pour baignoires autoportantes

Installation:

- Découpez un trou de 5" (12,7 cm) dans le sous-plancher (utilisez le gabarit ci-inclus).
- Affixez au sous-plancher avec 5 vis (non-incluses).
- Connectez l'ensemble de Drain au Siphon désiré dessous le plancher.

- Installez la surface de plancher, laissant une ouverture de 5" pour accès au Drain.
- Affixez le propre Tuyau de Rallonge en laiton au Trop-Plein de Baignoire. **NOTE: NE PAS COUPER LE TUYAU DE RALLONGE EN LAITON CAR CELA POURRAIT PROVOQUER UNE FUITE D'EAU.** Assurez-vous que la mesure entre la base du Drain et le Siphon va accueillir le Tube de Rallonge.

- Grippez la languette avec des serrures et déplacez-la d'avant en arrière jusqu'à ce qu'elle soit retirée. Appliquez du lubrifiant (fourni) au Tuyau de Rallonge.
- Placez la Baignoire en ligne avec le Drain.
- Abaissez avec précaution la Baignoire avec le Tuyau de Rallonge en laiton installée dans le collier rouge dans le Drain. Assurez-vous que le Tuyau de Rallonge est pleinement engagé avec le Joint d'Étanchéité.

Important: NE PAS COUPER LE TUYAU DE RALLONGE EN LAITON.

Cela pourrait provoquer une fuite d'eau. Le démontage du Drain ou le coupage du Tuyau de Rallonge annulera la garantie.

Certification:



Patented / Breveté